



Your New Remote

The Fleximo remote has been replaced by a new, more state-of-the-art model. We invite you to consult the information on the back of this page in order to take advantage of its many functions.

This information sheet replaces page 2 of the brochure entitled "How to use the On-Screen Interactive Guide."

Keep it for future reference.



Remote Control Features

Basic Navigation

- **Yellow** highlighting indicates your current selection as you navigate through the on-screen menus.
- Press the **◀▶▼▲** arrow buttons in the centre of your remote to move the highlighting.
- Press **OK** to confirm your selection.
- Press the **EXIT** button to exit the menus and return to watching TV.



¹ These buttons are available with Fleximo on Demand and the digital video recorder (DVR). Programs on demand cannot be recorded with the DVR.